
Tektronix[®]

80SJARB and 80SJNB Jitter, Noise, and BER Analysis Software for DSA8300 Sampling Oscilloscopes- Datasheet



High-speed serial data link measurements and analysis are supported with three software solutions. **80SJARB** is a basic jitter measurement tool capable of measuring jitter on any waveform – arbitrary or very long patterns. **80SJNB Essentials** (80SJNB) offers complete analysis of jitter, noise, and BER, with decomposition of components for a clear understanding of a signal's problems and margins. **80SJNB Advanced** (80SJNB02) adds Serial Data Link Analysis Visualizer (SDLA) functions to 80SJNB Essentials, including test fixture de-embedding, channel emulation, FFE/DFE equalization, and pre-emphasis/de-emphasis. The latest release of 80SJNB, PAM4, supports comprehensive analysis of multi-level signaling, including Pulse Amplitude Modulation (PAM-4) coded data.

Key features

- Jitter, noise, and BER analysis of high-speed PAM-4 and PAM-2 NRZ serial data rates from <1 Gb/s to 60 Gb/s provides insight into precise causes of eye closure
- Unmatched measurement system fidelity with ultra-low jitter floor for accurate and repeatable measurement results
- Separation of both jitter and noise provides highly accurate extrapolation of BER and eye contour
- Analysis of bounded uncorrelated jitter (BUJ) and noise handles the effects of crosstalk, avoids undue inflation of the RJ and TJ
- Analysis of PAM-4 signals with comprehensive jitter, noise and BER analysis for each individual PAM eye, and a set of global measurements that assess the PAM-4 signal overall attributes.
- J2, J9, and J<settable> measurements, DDPWS measurement and plot in support of IEEE 802.3ba 100 GbE

- Fixture de-embed removes the signal distortion caused by the measurement fixture
- Channel emulation from TDR waveforms or from S-parameters inserts virtual channel: Observe the signal as it will look at the end of the interconnect, even while capturing the transmitter waveform only
- Channel emulation recalculation: With just one transmitter acquisition, view the link performance for a number of emulated channels
- CTLE/FFE/DFE equalization of the signal opens the eye diagram for measurements – view the signal the way it is viewed by the receiver comparator
- Over 30 dB of channel loss can be equalized, supporting advanced backplane standards
- Large number of PAM-4 measurements for the new 400G / 100G standards
- Store and recall data set: Save transmitter data set, then recall this data set later and continue the data experiments


Applications


- Characterize jitter, noise, and BER performance of high-speed serial designs from 1 Gb/s to 60 Gb/s data rates; export waveforms for external analysis
- Characterize advanced links using CTLE/FFE/DFE equalization, and with DDPWS measurements
- Link budgeting and "what-if" analysis with emulation of a range of channels by using just one transmitter measurement
- Acquire precise waveform shape for simulations or other processing; rely on acquisition with state-of-the-art resolution, jitter, noise, and with fixture de-embedding support
- Characterize jitter, noise and BER performance of multi-gigabit standards such as OIF-CEI, KR4, SR4, ER4, LR4, LR8, FR8, DR4, CLR, PSMR, CAUI/XLAUI/CDAUI, 802.3 Ethernet, physical layer, XAUI, nAUI, Rapid I/O, XFI, SFP+, InfiniBand, and other electrical or optical standards
- Characterize jitter, noise, and BER performance of links using PAM-4 signaling
- Design validation and characterization of next-generation high-speed serial data computer and communications components and systems
- Transmitter measurement, measurements on stressed eye for Receiver test, component measurements
- Serial data link design and evaluation: Consider the alternatives for equalization with quick adjustments of the built-in flexible equalizer using a large number of taps and automatic tap weight calculation

- Save complete waveform data set information for future reuse. Then recall the data set for experiments with a new physical layer
- · Dedicated rising and falling transition time separation with full statistics

Transition	Mean(µ)	StdDev(o)	CV(σ/μ)	Min	Max	Count
0→1	14.8 ps	1.36 ps	0.0921	12.4 ps	17.5 ps	32
0→2	13.8 ps	0.89 ps	0.0646	12.4 ps	15.9 ps	32
0→3	14.3 ps	0.53 ps	0.0372	13.6 ps	15.9 ps	32
1→0	15.1 ps	0.97 ps	0.0645	12.8 ps	17.5 ps	32
1→2	13.3 ps	1.14 ps	0.0854	10.9 ps	17.1 ps	32
1→3	13.9 ps	0.80 ps	0.0573	12.4 ps	15.9 ps	32
2→0	13.7 ps	0.60 ps	0.0434	12.4 ps	14.7 ps	32
2→1	12.3 ps	0.87 ps	0.0705	10.5 ps	14.7 ps	32
2→3	15.5 ps	1.23 ps	0.0795	12.8 ps	17.8 ps	32
3→0	14.0 ps	0.71 ps	0.0509	13.2 ps	16.3 ps	32
3→1	13.8 ps	0.74 ps	0.0537	12.4 ps	15.9 ps	32
3→2	14.0 ps	1.07 ps	0.0761	11.6 ps	16.3 ps	32

 Advanced successive staging of CTLE equalizers, offers unique high precision tracking of emerging standards equalization needs





Jitter, Noise, BER, and Serial Data Link analysis software for Tektronix DSA8300 sampling oscilloscopes

The 80SJARB, 80SJNB Essentials, 80SJNB Advanced (80SJNB02), and PAM4 option software applications support high-speed serial data link measurements and analysis with the following capabilities:

Capability	80SJNB	80SJNB JNB01/ 80SJNB JNB02 ²	80SJNB PAM4 ²	80SJARB
NRZ Data Supported	Repetitive pattern <100,000 UI	Repetitive pattern <100,000 UI	Repetitive pattern <100,000 UI	Any patterns (including PRBS31)
PAM-4 Data Supported	No	No	Yes	No
J2 Jitter Result (settable to Jx)	Jx defaults to BER 2.5e ⁻³	Jx defaults to BER 2.5e ⁻³	Jx defaults to BER 2.5e ⁻³ for each PAM eye	J2 only (on a histogram according to IEEE 802.3ba), NRZ only
J9 Jitter Result (settable to Jx)	Jy defaults to BER 2.5e ⁻¹⁰	Jy defaults to BER 2.5e ⁻¹⁰	Jy defaults to BER 2.5e ⁻¹⁰ for each PAM eye	J9 only (extrapolated from a histogram according to IEEE 802.3ba)
TJ Total Jitter Result	Yes at target BER. Default BER = 1e ⁻¹²	Yes at target BER. Default BER = 1e ⁻¹²	Yes at target BER. Default BER = 1e ⁻¹² for each PAM eye	Yes at BER = 1e ⁻¹²
Jitter and Noise Analysis (RJ, DJ, BUJ, PJ, RN, DDN, BUN, PN)	Yes	Yes	Yes, for each PAM eye	RJdd, DjDD, Tj, for NRZ only
OMA/VMA	PI only NRZ eye	PI only NRZ eye	Yes, for each PAM eye	No
RIN, RINxOMA	Yes 1	Yes ¹	Yes ¹	No
BER Plots	Yes	Yes	Yes	No

¹ Available from the TekExpress® RIN application which is distributed with any version of 80SJNB applications


Capability	80SJNB	80SJNB JNB01/ 80SJNB JNB02 ²	80SJNB PAM4 ²	80SJARB
Global PAM-4 measur ements	No	No	Yes, transmitter level and receiver eye centric measurements	No
SDLA Features (Channel emulation, fixture de- embedding, equalization)	No	Yes ²	Yes ²	No

80SJNB PAM-4 signal analysis


The PAM4 option for 80SJNB adds full jitter, noise and BER analysis on PAM-4 modulated signals to support 100-400 Gbps electrical and optical communication links.

Signal impairment sources for PAM-4 are categorized in similar ways as those for NRZ systems: uncorrelated jitter and noise sources, crosstalk, bounded, and unbounded types. 80SJNB PAM4 performs the full analysis on each PAM eye, and also performs a set of global PAM-specific measurements.


Plots show different aspects of the signal: pattern, eye diagrams, horizontal and vertical bathtub curves, BER eyes and contours are all reflecting the three stacked eyes for a PAM-4 signal.



A key feature of the PAM-4 tool is to optimize the eye center reflecting a receiver with maximum horizontal and vertical margins. You have the option to lock the vertical slicer to a single phase for all three eyes.



The PAM-4 analysis has full signal path emulation tools that support Continuous Time Linear Equalizer (CTLE), channel emulators described by S-parameters or TDR waveforms, and receiver equalizers Feed Forward (FFE) and Decision Feedback (DFE).



80SJNB analysis tools

The advanced techniques employed by the designs call for advanced tools in the measurement solutions. The concerns begin with acquisition: capturing the data signal through physical fixture distorts signal shape; 80SJNB provides you with a fixture de-embedding feature ³ which allows you to remove the effects of the fixture from the measurement. The accuracy improvement might well mean the difference between a passing design and a failing one, because the impact of the fixtures on the signal fidelity today is large.

² JNB01 adds insertion loss emulation and FFE/DFE. JNB02 further adds SDLA Visualizer for additional CTLE and full and multi-stage de-embed and channel emulation. Only JNB01 and JNB02 can be further enhanced by option PAM4.

³ The tool for de-embedding filter creation is available free of charge from your Tektronix sales office.

And what is the shape of the transmitter signal you are capturing? The signal from the transmitter is no longer a simple NRZ square-wave pattern. Transmitter designers alleviate high-frequency loss in the media with transmitter equalization features, for example with preemphasis or deemphasis of the transmitter waveform. Correspondingly, transmitter signals today need to be evaluated for this transmitter equalization; your 80SJNB quickly provides equalizing tap weight results to give you insight into the quality of your transmitter for both single- and multi-tap transmitter equalization designs.

Measure jitter and noise

80SJNB revolutionized jitter analysis by adding noise analysis, critical to noise- and eye-closure-limited high-speed designs both for NRZ (PAM-2) and PAM-4 signals. Complete characterization of both jitter and noise allows 80SJNB to offer capability new for oscilloscopes – BER contours, found on BERT instruments like the Tektronix BERTScope Series.

80SJNB offers analysis that is aware of bounded uncorrelated disturbers (BUJ etc.). Bounded uncorrelated disturbers are a growing problem in fast, densely packed designs at 8 Gb/s and above, where they arise mostly from increased crosstalk. In older jitter and noise analysis tools they are typically mistaken for random, unbound components; classifying these components as unbound leads to inappropriate increase in random component breakdown (RJ) and total (TJ, TN) result. 80SJNB answers the challenge with a jitter and noise breakdown extended to properly classify the bounded uncorrelated disturbers in their own category, increasing the accuracy of the jitter/noise result.

Unique among jitter tools, 80SJNB breaks down the contribution of noise to jitter with RJ(v) and PJ(v). The breakdown quickly pinpoints the cause of jitter problems.

Beyond measurements at the transmitter


An important part of today's evaluation of serial data links is the complicated interaction between the shape of the measured waveform and the complex behavior of the interconnect channel. It is no longer possible to assume that if transmitter output meets the eye diagram mask it will work against all channels up to a given loss. Instead, advanced link test methods acquire the true transmitter waveform shape, and test against several corner-case channels.

Is the solution of emulating the channels based on their network description, for example, S-parameters? Such compliance tests are becoming a part of new standards. Now the measurement suite on your transmitter under test simply involves acquisition of the transmitter signal. Then you connect the captured signal to all required channels, one channel at a time – in emulation, rather than physically. 80SJNB supports this methodology; you can view the candidate channels without the need to reacquire the transmitter waveform. And unlike bare-bones evaluation scripts often used for pass/fail decisions the 80SJNB offers a rich set of views of the signal, starting with complete waveform, oversampled for high signal fidelity.

And of course the complete set of 80SJNB jitter and noise measurements is available to support your analysis of what problems, if any, your device might have. At the same time the BER eye offers a view of the link performance that matters most to the end user – in terms of BER performance and its margins. At the end of the test, save the waveform description data set for evidence or for future experiments; then recall and reanalyze whenever is needed without the need to reacquire.

80SJNB BER

Perhaps the single most important result of serial data link test is the BER; uniquely, the 80SJNB brings you the BER eye plot. While measurements on narrow parts of the signal are now common (jitter at the crossing, noise at the cursor), 80SJNB captures the whole signal, and then truthfully presents the accumulation of all impairments. Measurement results at a different decision threshold or timing point are just a click away, as the 80SJNB always keeps the whole 3-D shape and all waveforms behind it.



Mask testing

The communication industry (e.g. IEEE 802.3 100GBASE-LR4) has evolved mask testing from a basic test done on acquired data to a statistical-based methodology. In the past, testing was done by measuring the hit-ratio on the acquired eye and thus was done at a shallow BER. Statistical-based methods improve the repeatability and efficiency of the mask test on a larger population of data and as a direct result improve the ability to separate good and bad transmitters.

80SJNB Essentials adds support for the hit-ratio mask test and includes masks for common standards. Mask testing can be done on the waveform data or after de-embedding, channel emulation or equalization (requires 80SJNB02).

The 80SJNB Mask test goes beyond the standards' methodology and adds two new concepts:

First, you are not limited to measuring the eye diagram at the probability given by the acquired data, but can also measure at other probabilities calculated in the PDF space. For example, the hit ratio for a standard mask test may be one hit in 20,000 samples. This is supportable by the traditional mask testing available in an oscilloscope. However, for a hit ratio of one hit in 10 million samples, traditional mask testing would require an excessively long acquisition time; 80SJNB quickly calculates both of these hit ratios.

Second, since 80SJNB also calculates the BER eye surface, you can apply the mask test to a target Bit Error Ratio (such as the BER contour space). In other words, you can find the Bit Error Ratio for a given mask (a BER mask test). This approach provides a different insight into the overall system quality.

The PDF mask test is the traditional industry approach to assess the quality of a transmitter. The BER Mask test provides a test of the BER that the signal supports for the given mask. When a custom mask shape is needed, for example, based on a change in requirements, the shape can be easily modified in an ASCII file and used in either of the PDF or BER space.

De-embed, embed, and equalize

SDLA Visualizer and JNB Signal Path

JNB's Signal Path is now complemented with the advanced features of SDLA Visualizer. SDLA Visualizer extends the de-embedding and channel emulation capabilities of JNB signal path by offering a complete 4-port deembed that models not only the effects of insertion loss, but also models the effects of return loss and cross-coupling. SDLA Visualizer also complements the DFE/FFE receiver equalization support in JNB and adds the ability to model CTLE equalization.

SDLA Visualizer works with the Signal Path function built into JNB Advanced. After configuring SDLA Visualizer, selecting the desired test point, and applying the model, the filter for the selected test point will automatically be loaded into the Signal Path filter block.

If DFE or FFE equalization are required, those parameters can be quickly entered in the JNB Signal Path and then the final measurements can be done.

These are just a few examples of the many features available from SDLA Visualizer, for more details see the SDLA Visualizer datasheet available on www.tektronix.com.

Transmitter equalization measurements

Serial data transmitters employing pre-emphasis/de-emphasis can be evaluated and measured using the FFE equalization feature. The package can autoset the tap values on the received PRBS pattern, enabling evaluation of the value of taps that counter-equalize the transmitter preemphasis/de-emphasis.

Fixture removal, arbitrary filter

At high speeds the test fixture often significantly distorts the acquired signal. The Advanced package supports a filter block which can be used for the fixture removal. But the processing block is flexible, not dedicated; it can perform as an arbitrary filter instead, for example for simulation of preemphasis/de-emphasis schemes or for the use of filters created with SDLA Visualizer.

Channel emulation

The interaction between the true transmitter signal shape and the channel (interconnect) parameters is complex and not easily predictable from separate measurements. A reliable way to observe the performance of the whole serial link is by connecting the true transmitter waveform to the channel. The channel doesn't have to be physically present: the Advanced 80SJNB package offers channel emulation based on network measurements of the channel. In this situation a transmitter signal with or without pre-emphasis/de-emphasis can be captured; the channel can be emulated through its S-parameters or time-domain network description, such as the TDR/TDT traces, and the signal at the end of the emulated channel can be measured.

Equalize, then equalize again

The equalization in the transmitter is one tool in the arsenal of tricks for fighting the loss and dispersion in the interconnect: another one is the equalization at the receiver. Receiver equalization in most NRZ systems falls under either FFE (Feed Forward Equalization; also known as LFE – Linear Feedback Equalization), or DFE – Decision Feedback Equalization. A receiver equipped with equalization can decode signals that, when viewed as an eye diagram, are completely closed.

How to measure such signals? The 80SJNB equalization tools can open a completely closed eye, with your own equalizer tap values, or, at the push of a button, find equalization tap values on a PRBS pattern for you, for either a FFE or DFE equalizer. The speed of recalculation and the ease of use allows you to easily modify system parameters, such as the number and weight of taps, or the amount of pre or de-emphasis; you can verify the optimization of the design, or develop "what-if" scenarios.

For those cases where CTLE (Continuous Time Linear Equalization) is required SDLA Visualizer can quickly create the necessary filter and load it directly in JNB.

If you design or measure devices intended for the high-volume PC market you will appreciate the addition of operation on the SSC (Spread Spectrum Clocking) – another first in the sampling oscilloscope measurements. Using the DSA8300 or DSA/TDS/CSA8200 mainframes plus the 82A04 Phase Reference module, the 80SJNB not only measures your signals under the presence of SSC, it also measures the SSC parameters.

Beyond just analysis, 80SJNB presents the unmatched utility of separating the jitter caused by noise impairments versus its jitter-based component.

The platform

The 80SJNB Jitter, Noise, BER, and Serial Data Link Analysis software runs on the Tektronix DSA8300 Sampling Oscilloscope. This combination of state-of-the-art analysis software with the advantages of the Tektronix sampling oscilloscope mainframe, such as modular flexibility, uncompromised performance, and unmatched signal fidelity, gives you the tools for next-generation high-speed serial data design validation and compliance testing.

Network description tool

The 80SJNB Jitter, Noise, BER, and Data Link Analysis software in some cases uses network description information, such as S-parameters in the Touchstone format. We recommend Tektronix TDR hardware and Tektronix IConnect application software for high-quality Touchstone network description data. Amongst the advantages of using Tektronix TDR hardware and IConnect is the preservation of the DC values in the Touchstone matrix, which is typically lost with other measurement methods. 80SJNB will work with network description based on other measurement methods, such as VNA data; the DC measurement results will then typically have to be extrapolated in the 80SJNB.

Prerequisites

The 80SJNB software package is designed for use on the DSA8300 Sampling Oscilloscope.

Spread Spectrum Clocking (SSC) support requires the 82A04 Phase Reference module, which can only be used on the DSA8300.

80SJARB: Jitter analysis of arbitrary data



The 80SJARB jitter measurement application software for the Tektronix DSA8300 addresses IEEE 802.3ba applications requiring the J2 and J9 jitter measurements. It also enables basic jitter measurements for NRZ data signals including PRBS31, random traffic, and scrambled data. This provides an entry-level jitter analysis capability with simple Dual Dirac model jitter analysis and no hardware module requirements. 80SJARB can acquire continuously in "free run" mode, delivering acquisitions and updates beyond the IEEE minimum requirement of 10,000 data points. Plots include jitter bathtub curves for both measured and extrapolated data and a histogram of the acquired data.

Supported 80SJNB, 80SJARB measurements

80SJNB, 80SJNB02, PAM-4 Advanced Jitter, Noise, BER Analysis measurements

Measurement	Description (per every eye when PAM4)
BUJ (d-d)	Bounded uncorrelated jitter (Dual Dirac)
BUN(d-d)	Bounded uncorrelated noise (Dual Dirac)
DCD	Duty cycle distortion
DDJ	Data dependent jitter
DDN	Data dependent noise
DDN (lower)	Data dependent noise on low level
DDN (upper)	Data dependent noise on high level
DDPWS	Data dependent pulse width shrinkage
DJ	Deterministic jitter
DN	Deterministic noise
Eye Opening @ BER	Horizontal eye opening
Eye Opening @ BER	Vertical eye opening at specified BER
Jx @ BER	Defaults to J2, BER = 2.5e ⁻³
Jy @ BER	Defaults to J9, BER = 2.5e ⁻¹⁰
NPJ(d-d)	Non periodic jitter (Dual Dirac)
NPN(d-d)	Non periodic noise (Dual Dirac)
OMA	Optical Modulation Amplitude
PJ	Periodic jitter
PJ(h)	Horizontal component of periodic jitter
PJ(v)	Vertical component of periodic jitter
PN	Periodic noise
PN(h)	Horizontal component of periodic noise
PN(v)	Vertical component of periodic noise
RJ (RMS)	Total measured random jitter
RJ(d-d)	Random jitter in Dual Dirac model
RJ(h) (RMS)	Horizontal component of random jitter
RJ(v) (RMS)	Vertical component of random jitter
RN (RMS)	Total measured random noise
RN(h) (RMS)	Horizontal component of random noise

Measurement	Description (per every eye when PAM4)
RN(v) (RMS)	Vertical component of random noise
SSC frequency	Spread spectrum modulation frequency (limited support)
SSC magnitude	Spread spectrum modulation magnitude (limited support)
TJ @ BER	Total jitter at specified BER
TN @ BER	Total noise at specified BER
VMA	Voltage modulation amplitude
80SJNB PAM-4 glo	bal measurements
Center Deviation	Position of eye centers relative to middle eye
Effective Symbol Level 1	Effective symbol relative to average (L0, L1)
Effective Symbol Level 2	Effective symbol relative to average (L2, L3)
EH6/EW6 OIF-CEI	PAM4 eye height and width, per specification
Level <e></e>	Symbol levels: L0, L1, L2, L3
Level Deviation	Level separation relative to peak-to-peak
Level Linearity	PAM4 level linearity
Level Mismatch ratio (R _{LM})(Minimum level separation relative to peak-to-peak
Level Thickness	Level RMS at minimum inter-symbol interference
Level Time Deviation	Minimum inter-symbol interference level positions
Minimum Signal Level	Minimum of level separations
OMA outer	Optical modulation amplitude between L0 and L3

Measurement	Description (per every eye when PAM4)
Transition Timing	Rise/Fall on individual PAM trajectories
Vertical Eye Closure	Minimum eye amplitude over eye opening

- Plots: Jitter and Noise Components Probability Distributions, Spectral Distributions, Data Dependent Jitter and Noise and DDPWS vs. Bit, Data Pattern Waveform, Bathtub Curves for Jitter and Noise, BER Probability Map, BER Contour Diagrams, Q-Eye, Probability Distribution Eye Diagrams (Data pattern can be plotted after every Signal Path (SP) processing step), SSC (Spread Spectrum Clocking) Profile. When analyzing PAM-4 signals, plots for all three stacked eyes are shown. SSC support is deprecated above 12 GBd on PAM4.
- Data Logging: Query and Export of all Numeric Results. Export of Waveforms: Raw Acquired Pattern Waveform, Correlated Pattern Waveform, Correlated Pattern Waveform after Every Signal Path Processing Step, Probability Distribution Eye Diagrams, and Bathtub Curves.
- Mask Testing: Statistical mask testing in PDF or BER space. Mask hit ratio supported.

80SJARB basic jitter analysis of arbitrary data

Measureme nt	Description	
DJdd	Deterministic jitter (Dual Dirac model)	
J2	Total jitter for BER = 2.5e ⁻³	
J9	Total jitter for BER = 2.5e ⁻¹⁰	
RJdd	Random jitter (Dual Dirac model)	
Tj	Total jitter for BER = 1.0e ⁻¹²	

- Plots: Jitter/Eye Opening Bathtub, Histogram of Acquired Data.
- Free Run Mode: For continuous acquisitions and update beyond the IEEE minimum requirement of 10,000 data points.

Specifications

All specifications apply to all models unless noted otherwise.

Measurement characteristics

Jitter Floor (DSA8300)	With 82A04B: ≤100 fs _{RMS} ⁴
	Without 82A04B: ≤400 fs _{RMS}
Noise Measurement Accuracy	Matches underlying hardware capability, see sampling module data sheet for specifications. Acquired waveform must be live. Acquired waveform must be a fixed repetitive pattern of maximum pattern length: 100k UI Network description in either Touchstone S-parameters (one-, two-, or four-port supported; single-ended and differential entry supported) or in time-domain 'reference, waveform' format (time-domain format *.wfm of 8000 Series supported; time-domain format *.wfm of IConnect [®] supported)
Export Waveforms	Raw (acquired) waveform, correlated filtered waveform after every step of the Signal Path
Equalization Autoset Patterns	PRBS3 through PRBS16 (any pattern that can be analyzed can be also equalized)
Maximum SSC (spread spectrum clocking) ⁵	<5000 ppm analysis is supported
Maximum Number of Taps, FFE/ DFE	100/40; 1, 2, or 10 FFE taps / UI
Arbitrary Filter Description	Finite Impulse response Arbitrary Filter Description. Contact your Tektronix Technical Support Center (http://www.tek.com/service/) for other formats / format convertors.

80SJARB	Windows 7 or Windows XP equipped 8000 Series mainframe
80SJNB	DSA8300 Series mainframe configured with Option ADTRIG and with software release V5.*. MS Windows 7 (please contact the Tektronix field office for information on upgrading your mainframe if necessary)
	DSA8200 or older series mainframe with 80A06 Pattern Sync Module (plugged into the oscilloscope, or on a SlotSaver cable)
	Contact your local Tektronix sales office for details on configuring your existing TDS/CSA8200, TDS/CSA8000B, or TDS/CSA8000 to be compatible with 80SJNB

⁴ See 82A04B data sheet for details; 82A04B only supported in the DSA8300 and DSA8200 Series mainframes. See DSA8300 data sheet for details on jitter floor performance.

⁵ SSC is currently supported to 12 Gb/s. Controlled length cables are required for SSC acquisition; contact your application engineer for an application note.

Ordering information

Models

80SJNB	Jitter, noise, BER, and RIN/RINxOMA $^{\rm 6}$ measurement and analysis	
80SJNB02	Adds the following features to the 80SJNB package for SDLA support:	
	Fixture de-embedding/arbitrary linear filter support	
	Channel emulation (based on channel time- or frequency-domain measurements)	
	FFE/DFE Equalizer support	
80SJNB PAM4	Comprehensive analysis of PAM-4 signaling	
80SJARB	Basic jitter measurements	

DSA8300 preinstall options

Order the following options to preinstall 80SJARB, 80SJNB, or related software in a DSA8300 instrument:

Option JARB	Add 80SJARB to DSA8300
Option JNB	Add 80SJNB Essentials to DSA8300
Option JNB01	Add 80SJNB Advanced to DSA8300
Option JNB02	Add 80SJNB Advanced with SDLA Visualizer to DSA8300
Option PAM4	Add PAM4 Transmitter Analysis Software to DSA8300. Requires option JNB01 (80SJNB Advanced) or option JNB02 (80SJNB Advanced with SDLA Visualizer) software

- For users of the original (80SJNB V1.*) package, the 80SJNB Essentials (V2.*) is a free update. Download the free update from www.tek.com.
- You do not need to order 80SJARB when ordering 80SJNB, 80SJNB01, or 80SJNB02; it is included at no additional charge.
- 80SJARB is available to all licensed users of any version of 80SJNB at no charge. Simply download 80SJARB from the Tektronix Web site.

Instrument upgrade options

Instrument	Upgrade name	Upgrade option	
DSA8300	DSA83UP	JNB	Add 80SJNB Essentials to DSA8300
		JNB01	Adds 80SJNB Advanced version 1
		JNB02	Add 80SJNB Advanced version 2 (SDLA Visualizer)
		PAM4	Adds PAM-4 analysis (requires 80SJNB01 or 80SJNB02)
		JARB	Add 80SJARB to DSA8300
		ADDJNB01	Upgrade 80SJNB Essentials to 80SJNB01
		JNBTOJNB02	Upgrade from 80SJNB Essentials to 80SJNB02
		JNB01TOJNB02	Upgrade 80SJNB01 to 80SJNB02 (SDLA Visualizer)
DSA8200	DSA82UP	JNB	Add 80SJNB Essentials
		JNB01	Add 80SJNB Advanced version 1
		JNBADD01	Upgrade from JNB to JNB Advanced

⁶ RIN and RINxOMA measurements are taken using the TekExpress RIN application which is distributed with the 80SJNB and 80SJNB01 software.

80SJARB and 80SJNB Jitter, Noise, and BER Analysis



Tektronix is registered to ISO 9001 and ISO 14001 by SRI Quality System Registrar.

GPIB IEEE-488

Product(s) complies with IEEE Standard 488.1-1987, RS-232-C, and with Tektronix Standard Codes and Formats.

ASEAN / Australasia (65) 6356 3900 Belgium 00800 2255 4835* Central East Europe and the Baltics +41 52 675 3777 Finland +41 52 675 3777 Hong Kong 400 820 5835 Japan 81 (3) 6714 3086 Middle East, Asia, and North Africa +41 52 675 3777 People's Republic of China 400 820 5835 Republic of Korea +822 6917 5084, 822 6917 5080 Spain 00800 2255 4835* Taiwan 886 (2) 2656 6688

Austria 00800 2255 4835* Brazil +55 (11) 3759 7627 Central Europe & Greece +41 52 675 3777 France 00800 2255 4835* India 000 800 650 1835 Luxembourg +41 52 675 3777 The Netherlands 00800 2255 4835* Poland +41 52 675 3777 Russia & CIS +7 (495) 6647564 Sweden 00800 2255 4835* United Kingdom & Ireland 00800 2255 4835*

Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777 Canada 1 800 833 9200 Denmark +45 80 88 1401 Germany 00800 2255 4835* Italy 00800 2255 4835* Mexico, Central/South America & Caribbean 52 (55) 56 04 50 90 Norway 800 16098 Portugal 80 08 12370 South Africa +41 52 675 3777 Switzerland 00800 2255 4835* USA 1 800 833 9200

* European toll-free number. If not accessible, call: +41 52 675 3777

For Further Information. Tektronix maintains a comprehensive, constantly expanding collection of application notes, technical briefs and other resources to help engineers working on the cutting edge of technology. Please visit www.tek.com.

Copyright [©] Tektronix, Inc. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

21 Sep 2016 61W-18868-12

-

www.tektronix.com

Tektronix[®]