


T-BERD®/MTS-6000A and -8000 Platforms

8100-Series CWDM OTDR EVO Modules



Key Benefits

- Characterize fiber links with exact CWDM wavelengths per ITU-T G.694.2
- Test through CWDM multiplexers, optical add/drop multiplexers (OADM), and demultiplexers with central wavelength control
- Troubleshoot live networks with in-service testing feature
- Verify end-to-end continuity using the continuous wave source
- Eliminate OTDR interpretation errors with Smart Link Mapper (SLM) without compromising on test time

Key Features

- Optimized dynamic range to test through mux, OADM, and demux
- Headend/central-office testing with sequenced short acquisition
- Integrated continuous-wave light source with modulation capability
- Instantaneous traffic detection
- Central wavelength control for accurate mux/demux loss measurement

Applications

- Test any CWDM network configuration
- Qualify fiber links during CWDM installation
- Wavelength provisioning—test new wavelength routes without disrupting traffic on active channels
- In-service troubleshooting pinpoint the nature of a fault and its exact location

The JDSU CWDM module, part of the 8100-Series OTDR EVO family can connect anywhere on the fiber to characterize CWDM networks for commissioning, network upgrades, and troubleshooting with the insurance of workflow optimization and accurate fiber-link fingerprinting.

The optical performance of the CWDM module, combined with the T-BERD/MTS platform's suite of testing features, ensures that testing jobs are performed right the first time to successfully deploy and maintain metro- and mobile-backhaul networks.

Testing features include:

- Automatic multitest configuration
- Summary results table with PASS/FAIL analysis
- Linear trace interpretation with SLM (optional)
- Fast-Report onboard report generation

Platform Compatibility

T-BERD/MTS-6000A



Compact multilayer platform for network installation and maintenance

T-BERD/MTS-8000 (V2)



Scalable platform for multiple-layer and multiple-protocol testing



Specifications (Typical at 25°C)

General	
Weight	approx. 500 g (1.1 lb)
Dimensions (W x H x D)	213 x 124 x 32 mm (8.38 x 4.88 x 1.26 in)
Laser safety class (21 CFR)	Class 1
Distance units	Kilometer, meter, feet, and miles
Group index range	1.30000 to 1.70000 in 0.00001 steps
Number of data points	Up to 256,000 data points
Storage	Bellcore/Telcordia compatible Version 1.1 and Version 2.0

Distanc	ce Measurements	
Mode		Automatic or dual cursor
Display ran	nge	From 0.5 to 320 km
Display res	solution	1 cm
Cursor reso	olution	From 1 cm
Sampling r	resolution	From 4 cm
Accuracy	+0.75 m +sampling resolution +1.10	5 * x distance (excluding group index uncertainties)

Attenuation Measurements	
Mode	Automatic, manual, 2-point, 5-point, and LSA
Display range	1.25 to 55 dB
Display resolution	0.001 dB
Cursor resolution	From 0.001 dB
Linearity	$\pm 0.03 \text{ dB/dB}$
Threshold	0.01 to 5.99 dB in 0.01 dB steps

Reflectance/ORL Measurements	
Mode	Automatic or manual
Reflectance accuracy	±2 dB
Display resolution	0.01 dB
Threshold	−11 to −99 dB in 1 dB steps

^{*}Time-based controller/clock accuracy

Yes

OTDR Modules	8100 CWDM1E	8100 CWDM2E	8100 CWDM3E	8100 CWDM4E	8100 CWDM5E
Wavelength ¹	1551/1571/1591/1611 ±3 nm	1471/1491/1511/1531 ±3 nm	1431/1451 ±3 nm	1351/1371/1391/1411 ±3 nm	1271/1291/1311/1331 ±3 nm
Dynamic range ²	42 dB	42 dB	42 dB	42 dB	42 dB
Pulse width	3 ns to 20 μs	3 ns to 20 μs	3 ns to 20 μs	3 ns to 20 μs	3 ns to 20 μs
Event dead zone ³	0.8 m	0.8 m	0.8 m	0.8 m	0.8 m
Attenuation dead zone4	4.5 m	4.5 m	4.5 m	4.5 m	4.5 m
Continuous wave light source					
Wavelengths	all listed above				
Output power	0 dBm				
Stability	<±0.1 dB at 25°C, over 1 hour				
Operating modes ⁵	(W. 270 Hz. 330 Hz. 1 kHz. 2 kHz				

Automatic traffic detection

- 1. Measured at 10 μs
- 2. The one-way difference between the extrapolated backscattering level at the start of the fiber and the RMS noise level after 3 minutes averaging using the largest pulse width
- 3. Measured at $\pm 1.5~\text{dB}$ down from the peak of an unsaturated reflective event using the shortest pulse width
- 4. Measured at ± 0.5 dB from the linear regression using a FC/PC reflectance and using the shortest pulse width
- 5. Subtract 3 dB when used in modulation mode (270/330/1k/2k Hz)

Ordering Information

8100-Series CWDM OTDR EVO Modules		
Description	Part Number	
CWDM OTDR 1551/1571/1591/1611 nm	E81400TDRCWDM1E	
CWDM OTDR 1471/1491/1511/1531 nm	E81400TDRCWDM2E	
CWDM OTDR 1431/1451 nm	E8120CWDMOTDR3E	
CWDM OTDR 1351/1371/1391/1411 nm	E8140CWDMOTDR4E	
CWDM OTDR 1271/1281/1311/1331 nm	E8140CWDMOTDR5E	

Interchangeable Optical Connectors		
Description	Part Number	
Straight connectors	EUNIPCFC, EUNIPCSC, EUNIPCST, EUNIPCDIN, EUNIPCLC	
8° angled connectors	EUNIAPCFC, EUNIAPCSC, EUNIAPCDIN, ENIAPCLC	

 $For more information about the T-BERD/MTS-6000A \ and \ -8000 \ test \ platforms, refer to their respective \ data \ sheets.$

Network and Service Enablement Regional Sales

NORTH AMERICA	LATIN AMERICA	ASIA PACIFIC	EMEA	www.jdsu.com/nse
TOLL FREE: 1 855 ASK-JDSU	TEL: +1 954 688 5660	TEL: +852 2892 0990	TEL: +49 7121 86 2222	•
1 855 275-5378	FAX: +1 954 345 4668	FAX: +852 2892 0770	FAX: +49 7121 86 1222	